

ERROR : F0E6 F0E8 IGBT BREAKAGE
HOB NO WORK,RIGHT SIDE NO WORK,NO POT DETECTION:
SEE THE SERVICE BULLETIN IN DOCUMENTS

